

9-4148S

INSTALLATION TIP

Note: It is recommended to refer to an installation manual for complete installation instructions. Specifications subject to change without notice.

Measure the cylinder head top to bottom to insure the head has not been resurfaced. If it is under 3.785 a head saver shim kit must be used.

DATO ÚTIL PARA LA INSTALACIÓN

Nota: Se recomienda consultar un manual de instalación para instrucciones completas de instalación. Las especificaciones están sujetas a cambio sin previo aviso.

Mida el cabezal del cilindro de arriba a abajo para asegurarse que la superficie del cabezal no ha sido modificada (reacondicionada). Debe utilizarse un equipo de suplemento para protección del cabezal si esta medida es menor que 3.785.

CONSEIL D'INSTALLATION

Remarque : se reporter à un manuel d'installation pour obtenir des directives complètes. Les données techniques peuvent faire l'objet de modifications sans préavis.

On doit mesurer la culasse de haut en bas afin de s'assurer que sa surface n'a pas été refaite; si la mesure est inférieure à 3,785, on doit utiliser un ensemble de cales protège-culasse.