

CLOYES TIMING KITS



A Leader In Timing Systems

Cloyes delivers complete timing kits that are engineered for precision, durability, and optimal engine performance. All Cloyes kits offer a complete repair solution with all the necessary components for an easy install. Each part is CAD designed and manufactured using premium materials and tested for OE fit, form, and function. Backed by Limited Lifetime Warranty and over 100 years in engineering leadership with unmatched technical support and repair confidence in every component.

TIMING KIT OPTIONS











| | Base Sprocket Kit | Water Pump Kit | VVT Kit | K3 Kit | K6 Kit |
|---|--|--------------------------------------|--|--|--|
| The kits you need for the complete job. | ChainsTensionersGuidesSprockets | Base Sprocket Kit plus • Water Pump | Base Sprocket Kit plus VVT Phasers VVT Solenoids | Base Sprocket Kit plus VVT Phasers VVT Solenoids Water Pump | Base Timing Kit plus VVT Phasers VVT Solenoids Water Pump Accessory Belt Drive |
| GM I4 2.0L/2.2L/2.4L Ecotec | 9-4201S | 9-4201SWP | 9-4201SAVVT1 | 9-4201SA1K3 | 9-4201SAK6 |
| GM V6 3.0L/3.6L HFV6 | 9-0753S | 9-0753SWP | 9-0753SVVT | 9-0753SK3 | 9-0753SK6 |
| Ford V8 5.4L Triton | 9-0391S | 9-0391SBWP | 9-0391SBVVT1 | 9-0391SBK3 | 9-0391SBK6 |
| Ford V6 3.5L/3.7L Ecoboost | 9-0738S | 9-0738SWP | 9-0738SVVT1 | 9-0738SK3 | 9-0738SK6 |
| Nissan V6 3.5L VQ | 9-0720S | 9-0720SWP | 9-0720SVVT | 9-0720SK3 | -coming soon- |
| | | | | | |

NEED PRODUCT SUPPORT? CALL 479-646-1662 EXT. 228 INFO@CLOYES.COM

CLOYES.COM