

9-5176

INSTALLATION TIP

Note: It is recommended to refer to an installation manual for complete installation instructions. Specifications subject to change without notice.

To ensure proper performance of enclosed tensioner (Part # 9-5176), torque bolts to 61-70 in. lbs. (Torquing above 70-in. lbs. may warp tensioner body). Tensioner is to be installed without the use of sealers or gasket material.

DATO ÚTIL PARA LA INSTALACIÓN

Nota: Se recomienda consultar un manual de instalación para instrucciones completas de instalación. Las especificaciones están sujetas a cambio sin previo aviso.

Para asegurar el funcionamiento adecuado del tensor adjunto (pieza número 9-5176), apriete los pernos con un torque de 61-70 libras - pulgada. (Si se aprieta con un torque mayor de 70 libras - pulgada se puede deformar el cuerpo del tensor). El tensor debe ser instalado sin usar selladores ni material de empaquetaduras.

CONSEIL D'INSTALLATION

Remarque : se reporter à un manuel d'installation pour obtenir des directives complètes. Les données techniques peuvent faire l'objet de modifications sans préavis.

Pour assurer le bon fonctionnement du tendeur ci-inclus (n° de pièce 9-5176), serrer les boulons au couple de 61 à 70 po-lb. Un couple plus élevé risque de déformer le corps du tendeur. Ce dernier doit être installé sans utiliser de scellant ou de matériau d'étanchéité.