WARNING

FAILURE TO PROPERLY ACTIVATE THE TENSIONERS CAN LEAD TO **CATASTROPHIC ENGINE FAILURE**



SECONDARY TENSIONERS

PART NUMBER ... 9-5686

IN KITS

9-0738S, 9-0738SA, 9-0738SC, 9-0738SD, 9-0738SE, 9-0738SF, 9-0738SG, 9-0738SWP, 9-0738SVVT1, 9-0738SAVVT1, 9-0738SAVVT2, 9-0738SCVVT1

The Tensioners In This Application Are Shipped In Their Deactivated State

Please Follow The Installation/Activation Process Below To Avoid Catastrophic Engine Failure

Figure A ... Insert body of tensioner into the block and push until fully seated.

Figure B ... Once tensioner is installed, remove clip. THIS STEP DOES NOT ACTIVATE the tensioner. The clip is simply to avoid accidental activation while installing.



Cloves.com/tech-center/

Figure C ... After the cam phasers and chains are installed, YOU MUST THEN ACTIVATE THE TENSIONERS by pressing on the chain above the tensioner pad allowing the tensioner plunger to fully compress and release. Make sure the tensioners properly activate and apply spring pressure to the chains.



YOUR COMPLETE TIMING AUTHORITY TECHNICAL SUPPORT: 479-646-1662 Ext. 228 TECHSUPPORT@CLOYES.COM • CLOYES.COM © 2022 Cloyes. All Rights Reserved.

